

# swingo® 350 E

## Preparation



1 Ensure the machine is unplugged and check the mains for damage. If cable is damaged, do not use machine!



2 Mount squeegee.




3 Mount brush unit.



4 Fill solution tank with clean water and dose the cleaning solution.



5 Or use Diversey cleaning solution dosing system.



6 Release parking position by lifting machine a bit (parking position is flipped back automatically).



7 Plug in machine.



8 Turn machine on (left button), and start solution supply (right button).



9 Adjust solution flow manually.




10 Start vacuum motor.



11 Adjust height of the handle (use orange fixation for floated cleaning).



12 Start brush rotation by pressing the levers and clean the floor.



13 Front squeegee for removing the water when going backwards. Use the lever right-hand!



14 Clean the floor.



15 Switch OFF all functions of the machine, and then unplug the power cord.



16 Remove water sieves and rinse with water.




17 Drain, rinse and clean the recovery tank.



18 Remove and clean floater unit.



19 Empty fresh water tank and clean solution filter.



20 Bring machine into parking position by lifting machine a bit with its handle, and flipping the parking lever manually.



21 Remove and clean squeegee.



22 Remove and clean brush unit.



23 Periodically clean the spray bar.



24 Wipe machine with moist cloth.



25 Store machine with open lid for ventilation and in parking position.

## Operation

## Maintenance

# ATTENTION!

Do not use the machine before you have read and understood the operating instructions!  
Questions: 1-800-558-2332

