

## swingo 250µicro B

## **Preparation**



Remove orange cover tank from machine.



Remove battery from machine.



Fit clean brushes or pad holders with clean pads



Fit squeegee.



Remove white solution tank from orange cover tank.



Fill white solution tank with clean water. Dose cleaning product into solution tank.



Replace battery into machine.



Refit white solution tank into orange cover tank and refit into machine.





Set both water flow levers for application. 5 settings from low to high (-) or (+).



Disengage parking/ storage mode using foot pedal.



Engage squeegee using foot pedal.



Release orange height lever for operating position.



Squeeze orange control lever whist pressing vellow button to start.



Press vacuum button on/off.

Press water button on/off



Press orange button and move into upright position to lock handle for parking/storage.



Disengage squeegee by lifting up squeegee with foot.



Lower machine with locked handle to 45% to engage transport/storage wheels.



Remove orange tank cover to empty both tanks.



Open and remove clear recovery tank cover. Empty and rinse.

Replace orange

tank cover on

to machine.



Clean and replace ball float before next use.

Clean and rinse

and replace

brushes/pad

drives/pads.

Replace pads as needed.



Empty and rinse

Remove, check

and clean

squeegee.



Remove battery and place on Charger indicators: Green = charging Green flashing = no Red flashing = error





## ATTENTION!

Do not use the machine before you have read and understood the operating instructions! Questions: 1-800-558-2332

TASKI is one of four core areas of the Diversey business. © 2021 Diversey, Inc. All Rights Reserved. All logos and trademarks are owned by or licensed to Diversey, Inc. 91928-USG-master (11/21)











